

# Chapter Overview

Foreword	1
Chapter Overview	5
<b>Chapter 1</b> Intro, installation etc.	7
<b>Chapter 2</b> BASIS	17
<b>Chapter 3</b> ENERGY	147
<b>Chapter 4</b> ENVIRONMENT	261
<b>Chapter 5</b> VISUALIZATION	343
<b>Chapter 6</b> ECONOMICS	397
<b>Chapter 7</b> WINDPLAN (NOT included in ver. 2.7, see ver. 2.5)	
<b>Chapter 8</b> OPTIMIZATION	415
<b>Chapter 9</b> CFD-interface	455
<b>Chapter 10</b> eGRID	473
<b>Chapter 11</b> MCP	519
<b>Chapter 12</b> LOSS & UNCERTAINTY	553

- A: Extreme Wind
- B: Air Density
- C: Wake Models