

# WindPRO 2.9 User Guide

1. edition, July. 2013

**© Copyright and publisher:**

EMD International A/S  
Niels Jernes Vej 10  
9220 Aalborg Ø  
Denmark  
Tel: +45 9635 4444, fax: +45 9635 4446  
E-mail: [emd@emd.dk](mailto:emd@emd.dk), web: [www.emd.dk](http://www.emd.dk)

**Author:**

Per Nielsen, EMD International A/S

**Co-authors:**

Jens Villadsen, Jon Kobberup, Per Madsen, Thomas Jacobsen, Morten L. Thøgersen, Mads V. Sørensen, Thomas Sørensen, Lasse Svenningsen, Mauricio Motta and Karina Bredelle (EMD International A/S)  
Robin Funk, Stefan Chun, Peter Ritter (EMD-DE)

**Translation and proofreading**

Jay Haley, Paul Hannah and Nathan Curry (EN)  
Stefan Chun, Peter Ritter and Robin Funk (DE)  
Amado Perez (FR)  
Antoni Aniento (ES)  
Tore Wizelius (SE)  
Wang Xiaorong (CN)

**Layout:**

Mette Søvsø, EMD International A/S

**Print:**

Uni-Print

**Financial support**

Parts of the WindPRO software and user guide are funded by the Danish Energy Agency and by the EU Altener programme.

# Foreword

Welcome to “the World of WindPRO”, which is not only” a calculation tool, but an “expert system” based upon more than 30 years of experience within design, calculation, documentation and evaluation of wind farms.

Our many years of experience within the wind industry have been incorporated in WindPRO, and we continuously try to add new features to the software based on the latest research and development within the area and when new industry demands arise. New features added are based on a selection as not all new developments might be considered relevant or useful for the software user. We use our expertise and “hands-on” experience when choosing the new features we decide will add most value for the users. Furthermore, we test the quality and relevance of new research and development work before we decide to incorporate this in WindPRO.

A major strength of WindPRO is that it is an “all in one” handling tool of wind energy projects through the whole development process, starting from the first idea of a project, when rough data are downloaded and preliminary calculations are performed until the comprehensive and detailed calculations leading to the final approval by both local planning authorities and investors/banks.

Similar to other calculation software, the input data loading and processing in WindPRO is important to obtain correct results. Therefore, we continuously strive to add new intelligent features to the software, which both support the user when evaluating the quality of the input data and assist during the processing of the data.

Enjoy working with the software and help the world to be a better place by designing the right wind farm layouts at the right places.

Per Nielsen, Manager



---

## The manual in brief

Each chapter has its own table of contents. The main chapters are: **(New in latest version in bold)**

- Foreword
- Chapter Overview
- 1 Intro, installation etc.
- 2 BASIS
- 3 ENERGY – MODEL, METEO & PARK
- 4 ENVIRONMENT – DECIBEL, SHADOW, ZVI & IMPACT, NORD2000
- 5 VISUALIZATION - PHOTOMONTAGE, ANIMATION & 3D ANIMATION
- 6 ECONOMY - WINDBANK
- 7 ~~LANDSCAPE AND PLANNING (not included, please see ver. 2.5)~~
- 8 OPTIMIZATION (Energy & Noise)
- 9 ENERGY - CFD interface (Computation Fluid Dynamics interface) **(WAsP-CFD)**
- 10 ELECTRICAL - eGRID
- 11 ENERGY - MCP (Measure Correlate Predict)
- 12 ENERGY – LOSS & UNCERTAINTY
- 13 LOADS – Site Compliance
- 14 **Performance Check**

Appendixes are included in chapters where relevant. Further documentation, validation etc. are available at <http://help.emd.dk/WindPRO/> Direct link is found in WindPRO HELP menu FAQ (internet), which is continuously updated. In the WindPRO Help the entire manual is available with search options, etc.

In chapter 2 BASIS, all basic functions are described. These are also the basis for using all other modules.

In the beginning of each chapter there will be a STEP-BY-STEP guide, which gives a checklist getting to a calculation result.

Generally, each chapter is divided in a theoretical part describing models and methods, and a part describing how to use the software.

Module descriptions and print examples from the different modules can be found in the separate Module Description. This is also available at <http://www.emd.dk/WindPRO/Modules/>

Chapter 7, module WINDPLAN is no longer included due to low interest for this module. It is still possible to use this module with the former WindPRO ver. 2.5, but this is no longer supported.

# Chapter Overview

Foreword	1
Chapter Overview	5
<b>Chapter 1</b> INTRODUCTION, Installation & License activation	7
<b>Chapter 2</b> BASIS	17
<b>Chapter 3</b> ENERGY	167
<b>Chapter 4</b> ENVIRONMENT	303
<b>Chapter 5</b> VISUALIZATION	421
<b>Chapter 6</b> ECONOMICS	477
<b>Chapter 7</b> WindPLAN(not included, please see ver. 2.5)	
<b>Chapter 8</b> OPTIMIZATION	497
<b>Chapter 9</b> ENERGY, Model - CFD interface (To be replaced with WAsP-CFD)	537
<b>Chapter 10</b> eGRID	555
<b>Chapter 11</b> MCP	601
<b>Chapter 12</b> LOSS & UNCERTAINTY	635
<b>Chapter 13</b> SITE COMPLIANCE	667

<b>Chapter 14</b> PERFORMANCE CHECK	747
--	-----

<b>Appendixes</b>	781
-------------------	-----

---

A: Decibel

B: Air Density

C: Wake Models